

AVPOS BT31



Más información en www.avpos.es

FEATURES



- ① Data collecting indicator:it turns green when data uploading,turns off after successfully uploaded;
- ② The power indicator:it turns red when charging and turns off when fully charged;
- ③ Bluetooth indicator:it lights on blue continuously when connected to another Bluetooth device,and flashes blue when disconnected;

PRODUCT ADVANTAGES

- Wireless transmission visible distance up to 10 meters;
- Built-in flash memory supports breakpoints;
- Offline scan can store up to 5000 data;
- Support real-time upload/inventory mode;
- Support Android/IOS/Windows;
- Support HID-SPP/HID BLE protocol;
- Built-in buzzer;
- Support scan 1D barcode and 2D QR code;
- Support sleep time setting, standby time more than 7 days;
- Ip68 industrial rugged;

OPERATIONS GUIDE

- Press key for 3 seconds it will turn on;
- Turn on bluetooth of your device, search for QS-Scanner and connect it without pairing password;
- Scanned data can be instantly upload to current connected device;
- Default auto sleep time 30 seconds,when it stops work lasting 30 seconds it will enter into sleep status,press the scan button it will wake up and auto connect to current connected device;
- Turning off scanner(2 ways):
 - ① scanning "shutdown code" to turn off the scanner.
 - ② Turning off automatically after 1min idle state.
- Charge using a cradle charger;

BLUETOOTH CONNECT

- Mobile devices:
 - Turn on bluetooth scanner or scan barcode to pair Bluetooth indicator will begin to flash;
 - Turn on bluetooth of your device,search for "QS-Scanner" and then connect it;
 - Once pairing successfully, bluetooth indicator will light on;
- 2.4G:
 - Scan "One-key pairing" barcode;
 - Plug 2.4G connector into the USB port of PC;
 - Once paired,it will stop buzzer;

BARCODE SETTING

- PAIR :



One-key pairing



Shut down



French Windows



French Canadian Windows 95/98



French Canadian Windows XP/2000



Spanish Windows

- Bluetooth communication method;



\$BT # HID



\$BT # SPP



Real-time upload



Show battery

- Sleep time setting



Sleep set(%ALLTIMSET)



20 S(%ALLTIM00)



30 S(%ALLTIM01)



60 S(%ALLTIM02)



2 MINS(%ALLTIM03);



20 MINS(%ALLTIM06)



Never Sleep- (%ALL*TIDIS)

- Inventory mode



mode set(%ALLMEM-SET)



store all data(%ALLAEM-SET)



total data(%ALLMEM-ZS)



upload all datas(%ALLMEM-SC)



clear all datas(%ALLMEN-QC)



buzzer on



buzzer off



IOS keyboard access



RF upload buzzer on



RF upload buzzer off



vibration on



Swedish Windows



UK English Windows



Japanese Windows



Portuguese-Brazilian Windows



vibration off



firmware Ver(%Version)



hardware Ver(%HD Version)



reset factory(%Restore)

- User id setting

Set ID



➤ scan 10 digits ➤ scan digits (00-99)



show ID



hidden ID



0



1



2



3



4



5



6



7



8



9



KEYBOARD WEDGE COUNTRY TYPES - COUNTRY CODES



*Italian Windows

Asterisks (*) indicate default values



North American



German Windows



DISCLAIMER

- The company does not assume any responsibility for losses caused by natural disasters;
- The company does not assume any responsibility for any loss caused by the use of this product;
- The company does not assume any responsibility for the loss caused by improper use of communication hardware or software developed by the company;
- By obtaining information,data,files or other products and services through this product,the company does not provide any form of guarantee and technical support,and does not assume any responsibility;
- The company does not assume any form of guarantee or technical support responsibility for third-party software used by this product;
- As other wise stated,the company does not take guarantee for the accuracy of this document,reliability;