

## 2D Bluetooth Barcode Scanner User Manual

V1.0

### Factory Default



### Scanner Pair with Receiver

#### 1, One scanner pair with one receiver

##### 1> Connect to receiver



Note: Scan this barcode, the scanner will connect to receiver, scan this barcode again they will disconnect.

##### 2> Scan the bluetooth pair barcode in the receiver

#### 2, Multiple scanners pair with one receiver

##### 1> First scanner pair with the receiver as one scanner pair with one receiver mode

##### 2> NO. N scanner (N from 2 to 7) pair with receiver:

###### I. Scan Many-to-one mode with the first paired scanner

###### II. Pair rest scanner with the receiver as one scanner pair with one receiver mode



### 3> Quit multiple Scanners pair with one Receiver mode



Note: Scan this bar code, the receiver needs to re-plug will exit multi-scanners paired with one receiver mode.

### Connect to Mobile Device



Scan this code, then turn on Bluetooth feature on IPAD or other Mobile device, and searching till find this device (Bluetooth Scanner) and connect it.

### Keyboard ON or OFF in IOS Mode



Note: In IOS mode, if the keyboard on, scan this code the keyboard will off; if the keyboard off, scan this code the keyboard will on.

### Scan Mode



### Interfaces



### Suffix Settings



### Sensitivity



### Buzzer



### Illumination



### Aiming



### Convert Case



### USB Country Keyboard types



### Data encoding Method Configuration

Note: For the host in order to print Chinese data according to the specified encoding method, it can be configured by reading "Data encoding method".

- 1, GBK(GB2312), applies to Notepad, Excel etc software.
- 2, Unicode, applies to Word, QQ etc software.



### Add Letters as Prefix/Suffix

Note: Scan digit setting code to set, Eg, A corresponds to 1065, then set as scan digit 1065 in order.



### Invoice Mode



### Baud Rate



### Number Appendix

